

Lector de tarjetas P2 con cinco ranuras para tarjetas P2 e interfaces USB 2.0/IEEE 1394b

AJ-PCD20

High speed data transfer to Windows PC/Mac based Nonlinear Editor
Install the P2 drive into a 5 type bay on a desktop PC
With the AC adaptor, you can use it as a stand-alone external drive
USB2.0/IEEE 1394b Interface
P2 Card Drive with Five P2 card Slots.
Please click here for a list of operation manuals to download.



- Transferencia de datos de alta velocidad a editor no lineal basado en PC Windows/Mac
- Instale el lector P2 en una bahía de 5", en un PC de escritorio
- Con el adaptador AC puede usarlo como unidad externa independiente
- Interfaz USB2.0/IEEE 1394b

Lector de tarjetas P2 con cinco ranuras para tarjetas P2.

[Click aquí](#) para ver el listado de manuales de operaciones para descargar.

SPECIFICATIONS

URL: <https://business.panasonic.es/professional-camera/aj-pcd20>

CONTACT

Web: <https://business.panasonic.es/professional-camera/contact-us>